


11771

BMW 325 xi WAGON

GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 2,000 LBS. TRAILER WEIGHT & 200 LBS. TONGUE WEIGHT.
*****DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.*****

Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	D-55001	1 1/4" CURT BALL MOUNT
2	1	F-4	1/2" DIA. PIN & CLIP
3	16	7/16	WASHER
4	1	M12 - 1.50 x 70	HEX BOLT
5	1	1/2"	CONICAL TOOTHED WASHER
6	2	CM-SP6	.250 x 1.00 x 3.00" SQUARE HOLE SPACER
7	2	7/16-14 x 1 1/4	HEX BOLT
8	2	7/16-14	HEX FLANGE NUT



HITCH WEIGHT: 33 LBS.

INSTALL TIME: 40 MINUTES

INSTALL NOTES:

NO DRILLING REQUIRED
 FASCIA TRIMMING MAY BE NECESSARY

INSTALLATION STEPS

- 1) Remove (14) fasteners securing two (2) underbody panels.
- 2) Remove four (4) 12mm nuts from the bumper attachments on both sides which will be reused in step # 3. Also remove a 12mm bolt from the A-frame and return it to the owner. Place (4) washers per stud between the bumper attachments and the hitch plates on both sides as shown.
- 3) Lift the hitch into position over studs and secure with existing flange nuts as shown.
- 4) Attach mounting strap to the hitch using 7/16" fasteners as shown.
- 5) Place two (2) spacers between the hitch and the A-frame, and secure with 12mm bolt and conical toothed washer as shown. Reinstall the lower body panel and trim the fascia as needed.
- 6) Torque all 12mm fasteners to 62 lb-ft, and all 7/16" fasteners to 50 lb-ft.

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.